

TG310A	03/04-		E422H D86	E422KP D98 E11S03 D65 (70)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG330A	228 KW	D 2066 10/02-	E172H D35	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG350A	240 KW	D 0836 LF44 03/04-	E422H D86	E422KP D98 E11S03 D65 (70)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG360A	257 KW	D 2066 LF03 05/00-	E13H D47	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG390A	265 KW	D 2866 LF/24 03/04-	E422H D86	E422KP D98 E11S03 D65 (70)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG410A	287 KW	D 2066 LF02 04/00-	E13H D47	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG430A	301 KW	D 2866 LF/25/28/33 03/04-	E422H D86	E422KP D98 E11S03 D65 (70)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG440A	316 KW	D 2066 LF01 05/06-	E422H D86	E422KP D98	E428L E428LS	E10H02 (LH)
TG460A	312 KW	D 2066 Euro 5 04/00-	E13H D47	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG480A	338 KW	D 2876 LF/02/03/04 02/03-	E13H D47	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
TG480A	351 KW	D 2876 LF12 05/06-	E422H D86	E422KP D98	E428L E428LS	E10H02 (LH)
TG510A	354 KW	D 2676 LF01/12 Euro4/5 08/00-	E13H D47	E56KP D72 E11S03 D132 (70) (36)	E428L01 E428LS (LS)	T250W (LT) E10H02 (LH)
	375 KW	D 2876 LF05				

TG530A

10/02-

E13H D47

E56KP D72
E11S03 D132 (70)
(36)

E428L01
E428LS
(LS)

T250W (LT)
E10H02
(LH)

390 KW

D 2876 LF13

TG540A

06/06-

E422H
D86

E422KP D98

E428L01
E428LS
(LS)

E10H02
(LH)

397 KW

D 2676 LF11 Euro5

TG660A

09/02-

E161H
D28

E56KP D72
E11S03 D132 (70)
(36)

E428L01
E428LS
(LS)
E491L (23)

T250W (LT)
E10H02
(LH)

485 KW

D 2840 LF25

MAN-SÜ..



MAN



MAN-TGL