



E947LC (i.V.)
E947LI

FH 12	08/93-	03/02	H19W05 (17) R/SR52/1400/1700/MR62 H200W04 (12) H200W01 H10W06 (17) R/SR52/1400/1700/MR62 H200WN (10) H14W02 (SG) R/SR70/1400/1700	H18WK03 H7090WK30 (84)	E316L (23) -F B216584 E420L (23) E420LS (LS)	T250W (LT) (23)
FH 12-380	11/01-	D12A340/380/420/460	H200W01 H200WN (10) H200W04 (12) H18W11 (HYDG) E28H (32) (33) (34)	H200WDK H700WK (8)	E420L E420LS (LS)	T350W (LT)
279 KW FH 12-420	11/01-	D12D	H200W01 H200WN (10) H200W04 (12) H18W11 (HYDG) E28H (32) (33) (34)	H200WDK H700WK (8)	E420L E420LS (LS)	T350W (LT)
309 KW FH 12-460	11/01-	D12D	H200W01 H200WN (10) H200W04 (12) H18W11 (HYDG) E28H (32) (33) (34)	H200WDK H700WK (8)	E420L E420LS (LS)	T350W (LT)
338 KW FH 12-500	11/01-	D12D	H200W01 H200WN (10) H200W04 (12) H18W11 (HYDG) E28H (32) (33) (34)	H200WDK H700WK (8)	E420L E420LS (LS)	T350W (LT)
368 KW		D12D				
VOLVO-FE (Euro 4+5)	◀	VOLVO	▶	VOLVO-FH (Euro 4+5)		

FH (Euro 4+5)

09/05-



E947LC (i.V.)
E947LI

FH 13-400

09/05-

H200W04
H200WN (10)
H18W11 (HYDG)

H200WDK
H700WK (8)

T350W (LT)
E28H (33)

294 KW

D13A400

FH 13-440

09/05-

H200W04
H200WN (10)
H18W11 (HYDG)

H200WDK
H700WK (8)

T350W (LT)
E28H (33)

324 KW

D13A440

FH 13-480

09/05-

H200W04
H200WN (10)
H18W11 (HYDG)

H200WDK
H700WK (8)

T350W (LT)
E28H (33)

353 KW

D13A480

FH 13-520

09/05-

H200W04
H200WN (10)
H18W11 (HYDG)

H200WDK
H700WK (8)

T350W (LT)
E28H (33)

382 KW

D13A520


VOLVO-FH 12



VOLVO



VOLVO-FH 16



VOLVO

NKW

FE (Euro 4+5)
FE 240

177 KW

D7E240

FE 280





206 KW

D7E280

FE 320

235 KW

D7E320



Typenbezeichnung

Hilfe

05/06-
05/06-

E416H D86

E416KP D36
H7062WK30 (8)

E452L
E452LS (LS)

05/06-

E416H D86

E416KP D36
H7062WK30 (8)






E452L
E452LS (LS)

05/06-

E416H D86

E416KP D36
H7062WK30 (8)

E452L
E452LS (LS)



VOLVO

NKW

FH 16

08/93-

Typenbezeichnung

Hilfe

FH 16

08/93- 01//03

H10W06 (23)
H200W01 (9)
H14W02 (23)
H200WN (10)

H60WK03
H7090WK10 (8)

E317L
E767L OE: 20411815
E767LS OE: 20411816



E947LC (i.V.)
E947LI

T250W (LT) (23)

FH 16

D16A/B 470/520
01/03-

H200W04
H200WN (10)
E28H (32) (33) (34)

H200WDK
H700WK (8)

E767L OE: 20411815
E767LS OE: 20411816

H28WF (52)

FH 16

405 KW

D16C550
01/03-

H200W04
H200WN (10)
E28H (32) (33) (34)

H200WDK
H700WK (8)

E767L OE: 20411815
E767LS OE: 20411816

H28WF (52)

FH 16-580

449 KW

D16C610
02/06-

H200W04 (39)
H200WN (10)

H200WDK
H7062WK30 (8)

E767L OE: 20411815
E767LS OE: 20411816

FH 16-660

427 KW

D16E 580
02/06-

H200W04 (39)
H200WN (10)

H200WDK
H7062WK30 (8)

E767L OE: 20411815
E767LS OE: 20411816

485 KW

D16E 660

VOLVO-FH (Euro 4+5)



VOLVO



VOLVO-FLC